

Technical User Manual

Gas Pressure Regulator

R Serie 1" – 2"

Main Features



Direct-acting R Serie Gas Pressure Regulators According to 2014/68/EU Directive, EN334 and EN 14382

- Fail Open regulator
- Balanced valve or Ratio System
- Rugged construction for durability
- Wide pressure regulation range
- Full seal at zero flow
- Easy maintenance
- Optional minimum and/or maximum pressure slam-shut device
- With or Without SSV
- With electric position indicator SSV closed by an inductive proximity switch
- Internal Relief Valve
- Combined monitoring system
- Bypass system for to activate ssv easily

Technical Features

| | |
|---|---|
| Maximum allowable pressure –PS | 20 bar |
| Inlet pressure range –bPu | BP 0.1 – 16 bar MP – AP 0.1 – 20 bar |
| Outlet pressure range –Wd ⁽⁴⁾ | 15 - 4400 mbar |
| Allowable temperature –TS ⁽¹⁾ | -20 °C to +60 °C |
| Inlet gas temperature | -20 °C to +60 °C |
| Accuracy class –AC ⁽²⁾ | up to AC 5 |
| Lock-up pressure class –SG ⁽²⁾ | up to SG 10 |
| Nominal size –DN | 1" x 1" 1" x 1 1/2" 1 1/2" x 1 1/2" 2" x 2" |
| Connections ⁽³⁾ | Threaded Rp EN or NPT ASME |

⁽¹⁾ Low temperature version -40°C: available on request

⁽²⁾ Depending on working conditions

⁽³⁾ On request for other connection class

⁽⁴⁾ with different versions

Materials



| | |
|-------------------------------|--|
| Body ⁽¹⁾ | EN-GJS 500-7 |
| | Ø 185 mm Aluminium cast alloys (for service box) |
| | Ø 210 mm Aluminium cast alloys |
| | Ø 280 mm Aluminium cast alloys |
| Main Actuator ⁽²⁾ | |
| Seat ⁽²⁾ | Brass |
| Internal Parts ⁽²⁾ | Stainless steel and brass |
| Seals | NBR+canvas (powered by hot operation process) |
| Diaphragm | Synthetic rubber with fabric reinforcement |

⁽¹⁾ A 216 WCB: available on request

⁽²⁾ Other materials available on request

Gas Pressure Regulator, R Serie


**Design,
Operational Diagram**




Gas Pressure Regulator
DN 1"

Gas Pressure Regulator
DN 2"


Configurations




Gas Pressure Regulator
R25-40-40H




Gas Pressure Regulator
with Slum Shut Valve
R25-40-40H/S Serie




Gas Pressure Regulator
with Slum Shut Valve + Monitor
R25-40-40H-M/S Serie



Gas Pressure Regulator
R 50



Gas Pressure Regulator
with Slum Shut Valve
R 50/S Serie



Gas Pressure Regulator
with Slum Shut Valve + Monitor
R 50M/S Serie

Gas Pressure Regulator, R Serie

Change & revision history

| Date | Page | Reason | Statement |
|------|------|--------|-----------|
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

INDEX

| | |
|--|-------------------|
| Main Features, Technical Features, Materials | 1 |
| Desing, Operational Diagram, Configurations | 2 |
| Change & revision history..... | 3 |
| Index..... | 4 |
| Safety and Safe Use..... | 5 |
| Summary of symbols, terms and units..... | 6 |
| General Description and Operation | 7 |
| Environmental conditions, Pipe installation..... | 8 |
| Vent Lines for Safety..... | 9 |
| General Information for Connection..... | 10 |
| Connection of the sensing Lines..... | 11,12 |
| Mounting Position..... | 12 |
| Dimensions and Weights | 13,14 |
| Setting of the outlet pressure | 15,16,17,18,19 |
| Outlet Pressure Range and Setting Springs..... | 20 |
| Slum Shut Valve, Technical Features..... | 21 |
| Setting Procedure of the Slum Shut Valve | 22,23,24 |
| Shut Off Range and Setting Springs | 25 |
| Monitor Unit | 26 |
| Setting of the outlet pressure for monitor system..... | 26,27,28,29,30,31 |
| Equipment List for Maintenance and Repair..... | 33 |
| Personal Protective Equipmen List..... | 34 |
| R Serie Regulator R25 – R40 Maintenance and Repair | 35,36,37,38,39,40 |
| R Serie Regulator R40H Maintenance and Repair | 41,42,43 |
| R Serie Regulator R50 Maintenance and Repair | 44,45,46,47,48,49 |
| Safety Slum Shut Maintenance and Repair | 51,52,53,54,55,56 |

Safety and Safe Use

Warning Notes!

To safely use the equipment, observe the environmental conditions allowed and the data provided on the nameplate of the regulator and any accessories.

To avoid injury to persons, damage to property or the environment, the following warning notes must be observed!

Any opening of the valve, replacement of parts or modifications to the original product is the user's responsibility and is done at his own risk.

Caution!

- All activities (mounting, installation and service work, etc.) must be carried out by qualified staff.
- Ensure that the relevant national safety regulations are complied with.
- Any gas pressure regulator that experience a fall or shock must not be put into operation, as this can adversely affect the safety functions even if they do not exhibit any external signs of damage.
- Unsuitable gases or gas components lead to a loss of the safety shutoff function.
- It must not be possible for foreign bodies/particles to enter the gas pressure regulator, as this could have an adverse effect on the safety shutoff function.
- Gases with concentrations of >0.1% for H₂S and NH₃ are only permissible in connection with biogas version.
- Condensation is not permitted in the gas pressure regulator. If not observed, the safety functions are no longer ensured.
- In connection without slum shut valve, the gas pressure regulator must not be used as a safety device. Closing does not take place.
- The R serie gas pressure regulators are designed to withstand gas pressures up to 20 bar (BP model is 16bar) in standby mode or working. At a pressure of 20 bar (BP model is 16bar), the R serie gas pressure regulator remains safely closed or will safely work. If the maximum permissible operating pressure is exceeded, a valve shutdown must be initiated.
- The gas pressure regulator cannot be mounted or replaced while the gas valve is under pressure.
- The impulse pipe (pressure feedback) must be connected to the main outlet gas pipe, downstream from the gas pressure regulator observing a distance of at least 4 x the diameter of the main outlet pipe.
- The upstream and downstream pipes must be cleaned after being laid. Before commissioning, it is essential to ensure that no dirt particles have remained that could enter the gas pressure regulator.
- The slum shut valves supplied by Gastech may only be repaired by Gastech Repair Centers.

Summary of symbols, terms and units

The following table summarizes the symbols and relevant descriptions and unit considered in this chapter and/or used in this document. The symbols are listed in alphabetic order.

| Symbol | Terms | Unit |
|------------------|--|----------------|
| AC | Accuracy class | % |
| AG | Accuracy group | % |
| bpu | Inlet pressure range | bar |
| d | Relative density of natural gas at actual conditions | / |
| DN | Nominal size | / |
| DS | Differential strength | / |
| Δp | Differential pressure | bar |
| Δp_{min} | Minimum operating differential pressure | bar |
| IS | Integral strength | / |
| KG | Flow coefficient | See definition |
| LpA | Sound pressure level | EN 61672-1 |
| MIPd | Downstream maximum incidental pressure | Bar |
| p | Component operating pressure | Bar |
| pb | Atmospheric pressure (absolute pressure) | bar abs |
| pd | Outlet pressure | Bar |
| pdmax | Maximum outlet pressure | Bar |
| pds | Set point | Bar |
| pf | Lock-up pressure | Bar |
| pmax | Maximum component operating pressure | Bar |
| pn | Reference absolute pressure for normal conditions | bar abs |
| PS | Maximum allowable pressure | Bar |
| PSD | Specific maximum allowable pressure | Bar |
| pu | Inlet pressure | Bar |
| pumax | Maximum inlet pressure | Bar |
| pumin | Minimum inlet pressure | Bar |
| SG | Lock-up pressure class | % |
| SZ | Class of lock-up pressure zone | Lock-up time |
| TS | Maximum/minimum allowable temperature | °C |
| V | Gas velocity | m/s |
| Wd | Set range | Bar |
| Wds | Specific set range | Bar |

General Description and Operation


The main diaphragm (3) inside the actuator (2) is connected to the orifice plug (7) with the main shaft (4).

if outlet pressure exceeds the force of the set spring;

the main diaphragm (3) moves up, moves with the main shaft (4) orifice plug (7) attached to the main diaphragm (3) and closes the orifice (6), stopping the flow.

if the outlet pressure decreases further than the compression force of the regulating spring;


the main diaphragm (3) moves down, moves with the main shaft (4) orifice plug (7) attached to the main diaphragm (3) and opens the orifice (6), starting the flow.



Gas Pressure Regulator, R Serie

Environmental conditions

Gastech guarantees the product under the following storage and transportation conditions. All functions of products that are stored unused for more than 3 years should be checked.



Storage IEC 60721-3-1

| | |
|-----------------------|-------------|
| Climatic conditions | Class 1K3 |
| Mechanical conditions | Class 1M2 |
| Temperature range | -20...60 °C |
| Humidity | < 95 % r.h. |

Transport IEC 60721-3-2


| | |
|-----------------------|-------------|
| Climatic conditions | Class 2K2 |
| Mechanical conditions | Class 2M2 |
| Temperature range | -15...60 °C |
| Humidity | < 95 % r.h. |

Pipe installation

Maximum tightening torque of pipe



| Diameter | 25 1" | 40 1 1/2" | 50 2" |
|----------|---------|-------------|---------|
| BSP | 125Nm | 200Nm | 260Nm |
| NPT | 125Nm | 200Nm | 260Nm |




check the tightness at the pipe connection points

Gas Pressure Regulator, R Serie

Vent Lines for Safety

The discharge outlets on the regulator must be transported to the outside with a pipe. In indoor use, if the vent lines are not carried outside, gas may leak into the environment when the regulator fails. Creates a risk of fire and explosion.



Make sure the gas is conveyed to a non-hazardous area with the vent line. Natural gas will rise due to lower density than air, GPL will go down due to greater density than air. The density of the gas used should be analyzed and accumulations should be prevented.

Gas Pressure Regulator, R Serie


General Information for Connection

The bodies of the regulators have an arrow sign indicating the flow direction. The gas must flow in the same direction as the arrow on the body of regulator. Make sure that the flow direction is correct while the regulator is mounted to the installation. The gas must be filtered and must not contain particles larger than 5 microns.


The simplest installation should include the following equipment;

| Pos | Equipment |
|-----|--|
| 1 | Upstream Main Shut off Valve |
| 2 | Gas Filter with DP gauge |
| 3 | Pressure Gauge –for upstream and downstream |
| 4 | Manual Relief Valve –for upstream and downstream |
| 5 | Gas Pressure Regulator with SSV |
| 6 | Safety Relief Valve |
| 7 | Downstream Main Shut off Valve |

Standard Position



Angle Position



Connection of the sensing Lines

For a perfect pressure stabilization, follow the guidelines below;

- The impulse pipe (pressure feedback) must be connected to the main outlet gas pipe, downstream from the gas pressure regulator observing a distance of at least 4 x the diameter of the main outlet pipe.
- Do not install equipment (main ball valve, solenoid valve, gas meter, etc...) on the main pipe at the regulator outlet before the 6x distance after the regulator.
- Gas velocity can never exceed 40m/s in the main outlet pipe, recommended gas velocities are as follows;


$V_{max} = 30 \text{ m/s}$ for $1,5 < P_d < 4 \text{ bar}$

$V_{max} = 25 \text{ m/s}$ for $0,15 < P_d \leq 1,5 \text{ bar}$

$V_{max} = 15 \text{ m/s}$ for $P_d \leq 0,15 \text{ bar}$

To prevent the impulse connections of the sensing lines from collecting dirt and condensation, the following is required:

- Impulse pipe fittings are always connected to the top or horizontal axis of the pipe.
- The slope of the impulse pipe is always 5-10% towards the main pipe connection.



All pipe of sensing line must have pipes with a minimum inside diameter of 8 mm, recommend not to put valve on the impulse line.


Gas Pressure Regulator, R Serie

Connection of the sensing Lines

Calculate the gas velocity with the following formula;


$$v = 345.92 \times \frac{Q}{DN^2} \times \frac{1 - 0.002 \times Pd}{1 + Pd}$$

| | |
|--------|---|
| V | Velocity (m/s) |
| 345.92 | Numerical constant |
| Q | Flow rate under standard conditions (Stm ³ /h) |
| DN | Regulator nominal diameter (mm) |
| Pd | absolute outlet pressure in (bar) |




Mounting Position

Standard Position




Upside down position




Gas Pressure Regulator, R Serie

Dimensions and Weights

R Serie -without SSV




| DN | A | B | C | D | E | L | Wgt kg |
|-----------------------|-----|-----|-----|----|-----|-----|--------|
| 1" x 1" | 185 | 90 | 102 | 63 | 240 | 303 | |
| 1" x 1" BP-MP | 210 | 90 | 102 | 63 | 240 | 303 | |
| 1" x 1" AP | 210 | 100 | 102 | 63 | 250 | 313 | |
| 1 1/2" x 1 1/2" | 185 | 90 | 132 | 63 | 240 | 303 | |
| 1 1/2" x 1 1/2" BP-MP | 210 | 90 | 132 | 63 | 240 | 303 | |
| 1 1/2" x 1 1/2" AP | 210 | 100 | 132 | 63 | 250 | 313 | |
| 1" x 1 1/2" | 185 | 100 | 132 | 63 | 250 | 313 | |
| 1" x 1 1/2" BP-MP | 210 | 100 | 132 | 63 | 250 | 313 | |
| 1" x 1 1/2" AP | 210 | 100 | 132 | 63 | 250 | 313 | |
| 2" x 2" BP-MP | 280 | 155 | 156 | 80 | 440 | 510 | |
| 2" x 2" AP | 210 | 145 | 156 | 80 | 400 | 480 | |




Gas Pressure Regulator, R Serie

Dimensions and Weights

R Serie -with SSV



| DN | A | B | C | D | E | L | Wgt kg |
|-----------------------|-----|-----|-----|-----|-----|-----|--------|
| 1" x 1" | 185 | 90 | 102 | 215 | 240 | 455 | |
| 1" x 1" BP-MP | 210 | 90 | 102 | 215 | 240 | 455 | |
| 1" x 1" AP | 210 | 100 | 102 | 215 | 250 | 465 | |
| 1 1/2" x 1 1/2" | 185 | 90 | 132 | 215 | 240 | 455 | |
| 1 1/2" x 1 1/2" BP-MP | 210 | 90 | 132 | 215 | 240 | 455 | |
| 1 1/2" x 1 1/2" AP | 210 | 100 | 132 | 215 | 250 | 465 | |
| 1" x 1 1/2" | 185 | 100 | 132 | 215 | 250 | 465 | |
| 1" x 1 1/2" BP-MP | 210 | 100 | 132 | 215 | 250 | 465 | |
| 1" x 1 1/2" AP | 210 | 100 | 132 | 215 | 250 | 465 | |
| 2" x 2" BP-MP | 280 | 155 | 156 | 245 | 440 | 685 | |
| 2" x 2" AP | 210 | 145 | 156 | 255 | 400 | 655 | |



Mounting position

SETTING


Gas Pressure Regulator, R Serie

Setting of the outlet pressure R25 – R40 – R40H

⚠ Make sure that all safety precautions (staff, environment, system) are taken before following the instructions below.

Operation







| Pos | Practice |
|-----|--|
| 1 | Remove the protective cap A. |
| 2 | Turn the adjusting screw C using a Tubular Socket wrench SW 30 mm. |
| 3 | Turning clockwise: the preload of the setpoint spring is increased and the outlet pressure is increased (+). |
| 4 | Turning counter-clockwise: the setpoint spring is released and the outlet pressure reduced (-). |
| 5 | After the setting: screw on the protective cap A again. |



Setting of the outlet pressure R25 – R40 – R40H

 Make sure that all safety precautions (staff, environment, system) are taken before following the instructions below.

With All Details

| Pos | Practice |
|-----|---|
| 1 | Open the manual vent valve on the outlet side to 30% (2). |
| |  Remember the gas will discharge, check the safety requirements again |
| 2 | Make sure the main outlet valve is closed (5) |
| 3 | Open the main inlet valve (1) slowly and observe the outlet pressure gauge (3) |
| |  Check the inlet pressure on the inlet manometer. Check that the inlet pressure is at the system design value. If the inlet pressure is lower or higher than the design pressure, contact your gas supplier. |
| |  In the first pressurization, the outlet pressure may increase by 30-60%, since the outlet vent valve is open, the high pressure will be discharged and the regulator reflex will recover after a while. |
| |  Check the pressure gauge (3) on the outlet pressure side, if the outlet pressure rises unreasonably, close the inlet main valve (1). |
| 4 | Close the manual vent valve on the outlet side (2). |
| |  Check the outlet pressure gauge (3), the outlet pressure should not rise more than 10% from the outlet pressure (on the label Pd Value). |
| | If the outlet pressure is not at the required value; |
| 5 | Open the manual vent valve on the outlet side to 30% (2). |
| 6 | Remove the protective cap A. |
| 7 | Turn the adjusting screw C using a Tubular Socket wrench SW 30 mm. |
| | Turning clockwise: the preload of the setpoint spring is increased and the outlet |
| 7a | pressure is increased (+). |
| | Turning counter-clockwise: the setpoint spring is released and the outlet pressure |
| 7b | reduced (-). |
| 8 | After the setting: screw on the protective cap A again. |
| 9 | Close the manual vent valve on the outlet side (2). |
| |  Check the outlet pressure gauge (3), the outlet pressure should not rise more than 10% from the calibrated outlet pressure |
| | Close all valves (1)(2)(5), check leakage control with inlet and outlet manometers (3) and foaming liquid |
| 9 | |
| 10 | If there is a leak, fix it and repeat step 9. |
| 11 | Return to step 1 |
| 12 | Open the main outlet valve slowly and ensure gas supply to the system |


Gas Pressure Regulator, R Serie

Setting of the outlet pressure R50

 Make sure that all safety precautions (staff, environment, system) are taken before following the instructions below.

Operation







| Pos | Practice |
|-----|--|
| 1 | Remove the protective cap A. |
| 2 | Turn the adjusting screw C using an open-ended wrench SW 24 mm. |
| 3 | Turning clockwise: the preload of the setpoint spring is increased and the outlet pressure is increased (+). |
| 4 | Turning counter-clockwise: the setpoint spring is released and the outlet pressure reduced (-). |
| 5 | After the setting: screw on the protective cap A again. |



Setting of the outlet pressure R50

 Make sure that all safety precautions (staff, environment, system) are taken before following the instructions below.

With All Details

| Pos | Practice |
|-----|---|
| 1 | Open the manual vent valve on the outlet side to 30% (2). |
| |  Remember the gas will discharge, check the safety requirements again |
| 2 | Make sure the main outlet valve is closed (5) |
| 3 | Open the main inlet valve (1) slowly and observe the outlet pressure gauge (3) |
| |  Check the inlet pressure on the inlet manometer. Check that the inlet pressure is at the system design value. If the inlet pressure is lower or higher than the design pressure, contact your gas supplier. |
| |  In the first pressurization, the outlet pressure may increase by 30-60%, since the outlet vent valve is open, the high pressure will be discharged and the regulator reflex will recover after a while. |
| |  Check the pressure gauge (3) on the outlet pressure side, if the outlet pressure rises unreasonably, close the inlet main valve (1). |
| 4 | Close the manual vent valve on the outlet side (2). |
| |  Check the outlet pressure gauge (3), the outlet pressure should not rise more than 10% from the outlet pressure (on the label Pd Value). |
| | If the outlet pressure is not at the required value; |
| 5 | Open the manual vent valve on the outlet side to 30% (2). |
| 6 | Remove the protective cap A. |
| 7 | Turn the adjusting screw C using an open-ended wrench SW 24 mm. |
| | Turning clockwise: the preload of the setpoint spring is increased and the outlet |
| 7a | pressure is increased (+). |
| | Turning counter-clockwise: the setpoint spring is released and the outlet pressure |
| 7b | reduced (-). |
| 8 | After the setting: screw on the protective cap A again. |
| 9 | Close the manual vent valve on the outlet side (2). |
| |  Check the outlet pressure gauge (3), the outlet pressure should not rise more than 10% from the calibrated outlet pressure |
| | Close all valves (1)(2)(5), check leakage control with inlet and outlet manometers (3) and foaming liquid |
| 9 | |
| 10 | If there is a leak, fix it and repeat step 9. |
| 11 | Return to step 1 |
| 12 | Open the main outlet valve slowly and ensure gas supply to the system |



Gas Pressure Regulator, R Serie

Outlet Pressure Range and Setting Springs

The spring setting ranges for R25 – R40 – R40H regulator are shown in the tables below

| Pressure Range (mbar) | Actuator (∅) | Color |  | Diameter (mm) | Order Code |
|-----------------------|---------------|--------------|---|---------------|------------|
| 20 – 35 | 185 or 210 BP | Grey |  | 2.5 | 2.13.0277 |
| 30 – 50 | 185 or 210 BP | Yellow |  | 2.8 | 2.13.0668 |
| 40 – 70 | 185 or 210 BP | Blue |  | 3.0 | 2.13.0701 |
| 50 – 130 | 185 or 210 BP | Black |  | 3.2 | 2.13.0702 |
| 110 – 200 | 185 or 210 MP | Orange |  | 3.5 | 2.13.0703 |
| 140 – 250 | 185 or 210 MP | Purple |  | 3.7 | 2.13.0704 |
| 200 – 360 | 185 or 210 MP | Pink |  | 4.0 | 2.13.0004 |
| 250 – 450 | 185 or 210 AP | Red |  | 4.5 | 2.13.0667 |
| 400 – 600 | 185 or 210 AP | Green |  | 5.0 | 2.13.0666 |
| 500 – 900 | 185 or 210 AP | Silver |  | 5.5 | 2.13.0705 |
| 700 – 1200 | 185 or 210 AP | Black+White |  | 6.0 | 2.13.0416 |
| 1000 – 1600 | 185 or 210 AP | Purple+White |  | 6.5 | 2.13.0657 |
| 1400 – 2500 | 185 or 210 AP | Grey+White |  | 7.5 | 2.13.0658 |
| 2200 – 3600 | 210 AAP | White |  | 12.0 | 2.13.0700 |
| 3400 – 5000 | 210 AAP | Orange |  | 13.0 | 2.13.0414 |

The spring setting ranges for R50 regulator are shown in the tables below

| Pressure Range (mbar) | Actuator (∅) | Color |  | Diameter (mm) | Order Code |
|-----------------------|--------------|--------|---|---------------|------------|
| 16 – 20 | 280 BP | Grey |  | 3.5 | 2.13.0696 |
| 20 – 35 | 280 BP | Yellow |  | 4.0 | 2.13.0670 |
| 30 – 50 | 280 BP | Blue |  | 4.5 | 2.13.0281 |
| 50 – 80 | 280 BP | Black |  | 5.0 | 2.13.0697 |
| 80 – 120 | 280 MP | Orange |  | 5.5 | 2.13.0671 |
| 110 – 170 | 280 MP | Purple |  | 6.0 | 2.13.0669 |
| 130 – 220 | 280 MP | Pink |  | 6.5 | 2.13.0698 |
| 180 – 330 | 280 MP | Red |  | 7.0 | 2.13.0594 |
| 200 – 350 | 280 MP | Green |  | 7.5 | 2.13.0089 |
| 350 – 600 | 210 AP | Black |  | 8.0 | 2.13.0695 |
| 600 – 1000 | 210 AP | Purple |  | 9.0 | 2.13.0699 |
| 800 – 1600 | 210 AP | Grey |  | 10.0 | 2.13.0412 |
| 1400 – 2400 | 210 AP | Pink |  | 11.0 | 2.13.0662 |
| 2200 – 3600 | 210 AP | White |  | 12.0 | 2.13.0700 |
| 3400 – 5000 | 210 AP | Orange |  | 13.0 | 2.13.0414 |

Gas Pressure Regulator, R Serie

Slum Shut Valve

The R series of regulators can be fitted with safety shut-off valve for overpressure (OPSO) or combined under-and-over pressure (UPS/O/OPSO) protection. Shutoff gas flow when the outlet pressure of the regulator increases or/and decreases. The Slum shut valve trip pressure can easily be adjusted independently of the regulator set point. Built internal bypass, for balancing pressure before relatching the safety shut-off valve, is operated by pulling the valve stem. Possibility of application of devices for remote signal and remote control.

Technical Features


| | |
|--|--|
| Type | IS |
| Operation class | A |
| Response time | < 2 s |
| Allowable temperature –TS ⁽¹⁾ | -20 °C to +60 °C |
| Accuracy –AG ⁽²⁾ | up to 0.05 bar AG 30 |
| | 0.05 – 0.15 bar AG 10 |
| | 0.15 – 5.5 bar AG 5 |
| Set Range OPSO ⁽³⁾ | BP 20 -300mbar MP 50 - 500mbar AP 0.3 – 5.5bar |
| Set Range OPSO ⁽³⁾ | BP 10 -280mbar MP 20 - 350mbar AP 0.2 – 3.2bar |

⁽¹⁾ Low temperature version -40°C: available on request


⁽²⁾ Depending on working conditions

⁽³⁾ change differant springs Refer to page

Setting Procedure of the Slum Shut Valve



SSV Unit for R25-40-40H-50



⚠ SSV units have a built-in bypass system for safety and easy installation. When you pull the cover, the bypass system is activated and the outlet is slowly pressurized. If the outlet main valve is not closed; It takes too long to fill out the exit and you cannot activate SSV.

Gas Pressure Regulator, R Serie

Setting Procedure of the Slam Shut Valve (Maximum and Minimum)

| Pos | Practice |
|-----|--|
| 1 | Use ring nut (B) to completely load maximum pressure spring (A). Loosen adjusting screw (D) to completely relieve minimum pressure spring (C). |
| 2 | Use a small pump or other appropriate means to raise pressure to normal operating level on the downstream vent valve (2). |
| 3 | Relatch controller and allow pressure to drop to minimum pressure triggering level. |
| 4 | Using adjusting screw (D), slowly load minimum pressure spring (C) until actuator triggers. |
| 5 | Repeat steps 2 and 3 above, making any necessary adjustments in setting. Least three times |
| 6 | Bring pressure back to normal values. |
| 7 | Relatch controller and raise pressure until it reaches maximum pressure triggering level. |
| 8 | Using ring nut (B), slowly unload spring (A) until actuator triggers. |
| 9 | Repeat steps 6 and 7 above, making any necessary adjustments in setting. Least three times |
| 10 | Close the downstream vent valve (2) and disconnect the external pressure source. |

 It is recommended that slam-shut controller efficiency be checked periodically.

Cut-off Test

| Pos | Practice |
|-----|---|
| 1 | Close inlet and outlet main valves (1) (5). The controller should trigger at minimum pressure (only if so set). |
| 2 | Using a small pump or other appropriate means on the downstream vent valve (2) , raise pressure in the line to normal operating level. Relatch controller in case it has triggered following on step 1 above. |
| 3 | Simulate pressure increase until maximum triggering pressure is reached. |
| 4 | Bring the line back to full operating conditions as described in Startup procedure. |

Controller-seal Check


| Pos | Practice |
|-----|---|
| 1 | Slowly close the main outlet valve (5) located downstream. |
| 2 | Disable the ssv unit and close the stream |
| 3 | Loosen one fitting in the line downstream of the slam-shut valve and apply soapy water in order to make sure that there are no leaks. In case of any leak being detected, proceed with the necessary maintenance of the controller. |

Gas Pressure Regulator, R Serie

R Serie Regulator Startup of the Slum Shut Valve

Previously calibrated

| Pos | Practice |
|-----|--|
| 1 | Make sure that the main inlet and outlet valves are closed. |
| 2 | Open the main inlet valve (1) slowly |
| 3 | Remove cap (E) reverse and screw it onto stem (F). |
| 4 | Pull cap (E) and keep it pulled several seconds until outlet pressure stabilizes, and SSV is easily activated. |
| | <p>☞ SSV units have a built-in bypass system for safety and easy installation. When you pull the cover, the bypass system is activated and the outlet is slowly pressurized. If the outlet main valve is not closed; it takes too long to fill out the exit and you cannot activate SSV.</p> |
| 5 | Open the main outlet valve slowly and ensure gas supply to the system |
| 6 | Repeat the above procedure, making sure that controller remains properly latched, then mount cap back in its original position |








Shut Off Range and Setting Springs

Over- Shut off setting ranges for the all diameters are shown in the tables below

| Pressure Range (mbar) | Actuator (∅) | Color |  | Diameter (mm) | Order Code |
|-----------------------|--------------|--------|---|---------------|------------|
| 30 – 125 | 120 BP-MP | Red |  | 2.2 | 2.13.0713 |
| 65 – 280 | 120 BP-MP | Blue |  | 2.5 | 2.13.0280 |
| 80 – 370 | 120 BP-MP | Yellow |  | 2.7 | 2.13.0714 |
| 280 – 490 | 120 BP-MP | Black |  | 3.2 | 2.13.0066 |
| 480 – 1000 | 120 AP | Purple |  | 3.5 | 2.13.0682 |
| 750 – 1250 | 120 AP | Silver |  | 3.7 | 2.13.0683 |
| 1000 – 1750 | 120 AP | Pink |  | 4.0 | 2.13.0744 |
| 1500 – 2500 | 120 AAP | White |  | 4.5 | 2.13.0319 |
| 2000 – 5500 | 120 AAP | Orange |  | 5.0 | 2.13.0324 |

Over- Shut off setting ranges for the all diameters are shown in the tables below

| Pressure Range (mbar) | Actuator (∅) | Color |  | Diameter (mm) | Order Code |
|-----------------------|--------------|--------|---|---------------|------------|
| 15 – 35 | 120 BP-MP | Red |  | 1.2 | 2.13.0715 |
| 25 – 40 | 120 BP-MP | Blue |  | 1.5 | 2.13.0283 |
| 30 – 100 | 120 BP-MP | Yellow |  | 2.0 | 2.13.0716 |
| 60 – 240 | 120 BP-MP | Black |  | 2.3 | 2.13.0069 |
| 70 – 450 | 120 BP-MP | Purple |  | 2.5 | 2.13.0746 |
| 350 – 900 | 120 AP-AAP | Silver |  | 2.8 | 2.13.0320 |
| 700 – 3200 | 120 AP-AAP | Pink |  | 3.5 | 2.13.0745 |



Minimum difference between regulator and SSV settings (ΔP_w):
 BP-MP Model: 15% with a minimum difference of 10 mbar for UPSO, 20 mbar for OPSO
 AP-AAP Model : 20% with a minimum difference of 40 mbar for UPSO, 40 mbar for OPSO


Monitor Unit

The Monitor or emergency regulator is used as a safety device in gas pressure reduction systems. The purpose of this device is to protect the system against possible overpressure, while keeping the reduction line in service. To perform a periodic test on a monitoring regulator, increase the outlet set pressure of the working regulator and watch the outlet pressure to determine if the monitoring regulator takes over at the appropriate outlet pressure.

Monitor regulator is generally installed upstream of the active regulator. Although the function of the monitor regulator is different, the two regulators are virtually identical from the point of view of their mechanical components. Flow coefficients of the regulator puls line monitor system are about 15% lower than those of the active regulator alone.

Setting of the outlet pressure for monitor system


! Make sure that all safety precautions (staff, environment, system) are taken before following the instructions below.



Setting of the outlet pressure for monitor system

 Make sure that all safety precautions (staff, environment, system) are taken before following the instructions below.

With All Details


| Pos | Practice |
|---|--|
| 1 | Open the manual vent valve on the outlet side to 30% (10). Remember the gas will discharge, check the safety requirements again |
| 2 | Make sure the main outlet valve is closed (11) |
| 3 | Remove the protective cap A of active regulator (7). |
| 4 | Turn the adjusting screw C using an open-ended wrench SW 24 mm. |
| 5 | Turning the part with symbol (C) clockwise, set the output pressure of the active regulator(7) to the highest level. |
| 6 | Remove the protective cap A of monitor regulator (4). |
| 7 | Turn the adjusting screw C using an open-ended wrench SW 24 mm. |
| 8 | Set the monitor regulator(4) 10% above the required outlet pressure of the system |
| 9a | Turning clockwise: the preload of the setpoint spring is increased and the outlet pressure is increased (+). |
| 9b | Turning counter-clockwise: the setpoint spring is released and the outlet pressure reduced (-). |
| | Check pressure gauge (8), verify pressure is 10% higher than required outlet pressure |
| 10 | Adjust the monitor regulator to the required outlet pressure of the system |
| 11a | Turning clockwise: the preload of the setpoint spring is increased and the outlet pressure is increased (+). |
| 11b | Turning counter-clockwise: the setpoint spring is released and the outlet pressure reduced (-). |
| 12 | Check pressure gauge (8), verify pressure is outlet pressure of the system |
|  | Check pressure gauge (5), the inlet and outlet pressure of the monitor regulator must be equal. |
| 13 | Close the manual vent valve on the outlet side (11). |
| 14 | Check the outlet pressure gauge (8), the outlet pressure should not rise more than 10% from the calibrated outlet pressure of Monitor regulator. |
| 15 | Close all valves (1) (2) (6) (10) (12), check leakage control with inlet and outlet manometers (3) (5) (8) and foaming liquid |
| 16 | If there is a leak, fix it and repeat step 9. |
| 17 | Open the main inlet and outlet valve (1) (12) slowly and ensure gas supply to the system |

Gas Pressure Regulator, R Serie

If active regulator working

The monitor controls downstream pressure at the same point as the main regulator and is set a little higher than the latter. Under normal duty, the monitor is fully open as it detects a pressure value lower than its set value.


In normal operation of a wide-open configuration, the working regulator controls the system’s outlet pressure. With a higher outlet pressure setting, the monitor regulator senses a pressure lower than its setpoint and tries to increase outlet pressure by going wide open. If the working regulator fails, the monitoring regulator assumes control and holds the outlet pressure at its outlet pressure setting.



When the active regulator fails



In normal operation, the working regulator controls the outlet pressure of the system. The monitoring regulator’s working actuator controls the intermediate pressure and the monitoring regulator senses the system’s outlet pressure. If the working regulator fails, the monitoring pilot will sense the increase in outlet pressure and take control.

If, due to any regulator fault, downstream pressure increases, when it exceeds the tolerated level, the monitor comes into operation and adjusts pressure to its own set value.



Gas Pressure Regulator, R Serie


Setting of the outlet pressure for monitor system with SSV



SSV Unit for R25-40-40H-50


Setting of the outlet pressure for monitor system with SSV

With All Details

| Pos | Practice |
|---|---|
| 1 | Use ring nut (B) to completely load maximum pressure spring (A). Loosen adjusting screw (D) to completely relieve minimum pressure spring (C). |
| 2 | Use a small pump or other appropriate means to raise pressure to normal operating level on the downstream vent valve (11). |
| 3 | Relatch controller and allow pressure to drop to minimum pressure triggering level. |
| 4 | Using adjusting screw (D), slowly load minimum pressure spring (C) until actuator triggers. |
| 5 | Repeat steps 2 and 3 above, making any necessary adjustments in setting. Least three times |
| 6 | Bring pressure back to normal values. |
| 7 | Relatch controller and raise pressure until it reaches maximum pressure triggering level. |
| 8 | Using ring nut (B), slowly unload spring (A) until actuator triggers. |
| 9 | Repeat steps 6 and 7 above, making any necessary adjustments in setting. Least three times |
| 10 | Close the downstream vent valve (11) and disconnect the external pressure source. |
| 11 | Open the manual vent valve on the outlet side to 30% (11). |
| | Remember the gas will discharge, check the safety requirements again |
|  | Make sure the main outlet valve is closed (12) |
| 12 | Remove the protective cap A of active regulator (7). |
| 13 | Turn the adjusting screw C using an open-ended wrench SW 24 mm. |
| 14 | Turning the part with symbol (C) clockwise, set the output pressure of the active regulator(7) to the highest level. |
| 15 | Remove the protective cap A of monitor regulator (4). |
| 16 | Turn the adjusting screw C using an open-ended wrench SW 24 mm. |
| 17 | Set the monitor regulator(4) 10% above the required outlet pressure of the system |
| 18a | Turning clockwise: the preload of the setpoint spring is increased and the outlet pressure is increased (+). |
| 18b | Turning counter-clockwise: the setpoint spring is released and the outlet pressure reduced (-). |
| 19 | Check pressure gauge (8), verify pressure is 10% higher than required outlet pressure Adjust the monitor regulator to the required outlet pressure of the system |

Setting of the outlet pressure for monitor system with SSV

With All Details









| Pos | Practice |
|---|--|
| 19a | Turning clockwise: the preload of the setpoint spring is increased and the outlet pressure is increased (+). |
| 19b | Turning counter-clockwise: the setpoint spring is released and the outlet pressure reduced (-). |
| 20 | Check pressure gauge (8), verify pressure is outlet pressure of the system |
|  | Check pressure gauge (5), the inlet and outlet pressure of the monitor regulator must be equal. |
| 21 | Close the manual vent valve on the outlet side (11). |
| 22 | Check the outlet pressure gauge (8), the outlet pressure should not rise more than 10% from the calibrated outlet pressure of Monitor regulator. |
| 23 | Close all valves (1) (2) (6) (10) (12), check leakage control with inlet and outlet manometers (3) (5) (8) and foaming liquid |
| 24 | If there is a leak, fix it and repeat step 9. |
| 25 | Open the main inlet and outlet valve (1) (12) slowly and ensure gas supply to the system |


MAINTENANCE and REPAIR REGULATOR

Gas Pressure Regulator, R Serie

Equipment List for Maintenance and Repair

You must have the following hand tools for maintenance and repair. Check that the hand tools you use comply with the standards in your country.

| Equipment | R25 R40 | R40H | R50 | Images |
|------------------------------------|-----------|-------|----------------------------|---|
| Combination Wrench | 13 | 13 | 10, 13, 17, 19, 24, 28, 42 |  |
| Hex Key Wrench T-Handle | 5 | 4,5 | 5, 8 |  |
| Screwdriver Slotted | 8x150 | | 8x150 |  |
| Hook Wrench | | | 58/62, 80/90 |  |
| Double Ended Tubular Socket Wrench | 30,22,26 | 30,22 | 17, 22, 27 |  |
| Circlip Pliers, External | | | |  |
| Adjustable Wrench | 40 | 34 | 34 |  |
| O-ring Tool | | | |  |









 the unit of all dimensions is mm

Abbreviations will be used in maintenance and repair instructions


| Equipment | Abbreviations |
|--|---------------|
| Combination W rench | CW |
| Hex Key Wrench T-Handle | HK |
| Screwdriver S lotted | SS |
| Hook W rench | HW |
| Double Ended Tubular S ocket W rench | SW |
| Circlip P liers, External | CP |
| Adjustable W rench | AW |
| O -ring Tool | OT |

Personal Protective Equipmen List

All certified technical personnel must wear personal protective equipment. You must comply with the occupational safety rules of the local authorities you are in. You should use personal protective equipment that complies with the standards of the country you are in. Personal protective equipment must meet at least the following standards

| Equipment | Standard | Images |
|--------------------------|---------------------|---|
| Industrial safety helmet | EN 397:2012+A1:2012 |  |
| Safety goggles | EN 166:2001 |  |
| Ear muffs | EN 352-1:2002 |  |
| Protective coverall | EN 14605+A1 |  |
| Visibility vest | EN 20471 : 2013 |  |
| Safety shoes | EN 20345: 2004 |  |
| Protective mask | EN149:2001 |  |
| Safety glove | EN 1082-1:1996 |  |

R Serie Regulator R25 – R40 Ø210 Actuator BP-MP



Before carrying out any work, it is important to ensure that the line on which the regulator is installed has been shut off upstream and downstream, and discharged.

Tighten all threaded parts with the correct torque.

R Serie Regulator R25 – R40 Ø210 Actuator BP-MP


Reach the actuator part / change the main diaphragm

| Step | Practice | Equipment and size |
|------|---|--------------------|
| 1 | Unscrew and remove the locking protection cover (1) | |
| 2 | Turn counterclockwise and remove the adjustment screw (3) | HW30 |
| 3 | Remove the o-ring (2) from the spring cover (5). Clean the surface where the o-ring (2) is attached. Lubricate and replace new o-ring (2) with synthetic grease | |
| 4 | Undo and remove the nut and the screw (6) | HK5 |
| 5 | Remove the main cover (5) | |
| 6 | Unscrew and remove the locking nut (7) | HW22 |
| 7 | Remove the disc of the diaphragm (8) and remove the main diaphragm (9). Clean the surface where the main diaphragm (9) is attached. | |
| 8 | Fit the new main diaphragm (9). | |
| 9 | Fit the disc of the diaphragm (8). | |
| 10 | Insert the nut (7). Tork 30Nm | HW22 |
| 11 | Fit the main cover (5). Please check; direction of the vent piece (8.1) | |
| 12 | Insert the nuts into the screws (6). Do not damage the main diaphragm (9) when installing the screws (6), check that the holes are in the center | HK5 |
| 13 | Insert the the main spring (4) | |
| 14 | Turn clockwise and screws the adjustment screw (3). | HW30 |
| 15 | Turn clockwise and locking protection cover (1) | |


R Serie Regulator R25 – R40 Ø210 Actuator BP-MP

Reach the body part / replace the compensation membrane and the closing plug

| Step | Practice | Equipment and size |
|------|--|--------------------|
| 16 | Unscrew and remove the nut (13). | CW13 |
| 17 | Pulling up, separate the main actuator (11) from the regulator's. | |
| 18 | Remove the o-ring (12) from the main actuator (11). Clean the surface where the o-ring (12) is attached. Lubricate and replace new o-ring (12) with synthetic grease | OT |
| 19 | Pull and remove main block (10) | |
| 20 | Unscrew the old plug and install the new one (14) | |
| 21 | Replace main block (10) | |
| 22 | Put the main actuator (11) back into the body of the regulator. Make sure origin is under the main actuator | |
| 23 | Screw and remove the nut (13). | CW13 |



R Serie Regulator R25 – R40 Ø210 Actuator AP



Before carrying out any work, it is important to ensure that the line on which the regulator is installed has been shut off upstream and downstream, and discharged.

Tighten all threaded parts with the correct torque.


Gas Pressure Regulator, R Serie
R Serie Regulator R25 – R40 Ø210 Actuator AP
Reach the actuator part / change the main diaphragm

| Step | Practice | Equipment and size |
|------|---|--------------------|
| 1 | Unscrew and remove the locking protection cover (1) | |
| 2 | Turn counterclockwise and remove the adjustment screw (3) | HW30 |
| 3 | Remove the o-ring (2) from the spring cover (5). Clean the surface where the o-ring (2) is attached. Lubricate and replace new o-ring (2) with synthetic grease | OT |
| 4 | Undo and remove the nut and the screw (6) | HK5 |
| 5 | Remove the main cover (5) | |
| 6 | Unscrew and remove the locking nut (7) | |
| 7 | Remove the disc of the diaphragm (22) and remove the main diaphragm (8). Clean the surface where the main diaphragm (8) is attached. | OT |
| 8 | Fit the new main diaphragm (8). | |
| 9 | Fit the disc of the diaphragm (22) | |
| 10 | Insert the nut (7). Tork 40Nm | |
| 11 | Fit the main cover (5). Please check; direction of the vent piece (8.1) | |
| 12 | Insert the nuts into the screws (6). Do not damage the main diaphragm (8) when installing the screws (6), check that the holes are in the center | HK5 |
| 13 | Insert the the main spring (4) | |
| 14 | Turn clockwise and screws the adjustment screw (3). | HW30 |
| 15 | Turn clockwise and locking protection cover (1) | |

R Serie Regulator R25 – R40 Ø210 Actuator BP-MP


Reach the body part / replace the compensation membrane and the closing plug

| Step | Practice | Equipment and size |
|------|--|--------------------|
| 16 | Unscrew and remove the nut (23). | CW13 |
| 17 | Pulling up, separate the main actuator (11) from the regulator's. | |
| 18 | Remove the o-ring (13) from the main actuator (11). Clean the surface where the o-ring (13) is attached. Lubricate and replace new o-ring (13) with synthetic grease | OT |
| 19 | Pull and remove main block (12) | |
| 20 | Remove the o-ring (14) from the main blok. Clean the surface where the o-ring (14) is attached. Lubricate and replace new o-ring (14) with synthetic grease | OT |
| 21 | Unscrew and remove the nut (15). | SS |
| 22 | Remove the o-ring (16) from the main shaft. Clean the surface where the o-ring (16) is attached. Lubricate and replace new o-ring (16) with synthetic grease | OT |
| 23 | Unscrew the old plug and install the new one (18) | |
| 24 | Replace main block (12) | |
| 25 | Put the main actuator (11) back into the body of the regulator. Make sure origin is under the main actuator | |
| 26 | Screw and remove the nut (13). | CW13 |



Gas Pressure Regulator, R Serie

R Serie Regulator R40H Ø185 or 210 Actuator BP-MP-AP



Before carrying out any work, it is important to ensure that the line on which the regulator is installed has been shut off upstream and downstream, and discharged.

Tighten all threaded parts with the correct torque.

R Serie Regulator R40H Ø185 or 210 Actuator BP-MP-AP


Reach the actuator part / change the main diaphragm

| Step | Practice | Equipment and size |
|------|---|--------------------|
| 1 | Unscrew and remove the locking protection cover (1) | |
| 2 | Turn counterclockwise and remove the adjustment screw (4) | HW30 |
| 3 | Remove the o-ring (3) from the main cover (6). Clean the surface where the o-ring (3) is attached. Lubricate and replace new o-ring (3) with synthetic grease | OT |
| 4 | Undo and remove the nut and the screw (8) | HK5 |
| 5 | Remove the main cover (6) | |
| 6 | Unscrew and remove the locking nut (9) | SW22 |
| 7 | Remove the disc of the diaphragm (10) and remove the main diaphragm (11). Clean the surface where the main diaphragm (11) is attached. | OT |
| 8 | Fit the new main diaphragm (11). | |
| 9 | Fit the disc of the diaphragm (10) | |
| 10 | Insert the nut (9). Tork 30Nm | SW22 |
| 11 | Fit the main cover (6). Please check; direction of the vent piece (8.1) | |
| 12 | Insert the nuts into the screws (8). Do not damage the main diaphragm (11) when installing the screws (8), check that the holes are in the center | HK5 |
| 13 | Insert the the main spring (7) | |
| 14 | Turn clockwise and screws the adjustment screw (4). | HW30 |
| 15 | Turn clockwise and locking protection cover (1) | |


R Serie Regulator R40H Ø185 or 210 Actuator BP-MP-AP

Reach the body part / replace the compensation membrane and the closing plug

| Step | Practice | Equipment and size |
|------|--|--------------------|
| 16 | Unscrew and remove the nut (25). | CW13 |
| 17 | Pulling up, separate the main actuator (14) from the regulator's. | |
| 18 | Remove the o-ring (16) from the main actuator (14). Clean the surface where the o-ring (16) is attached. Lubricate and replace new o-ring (16) with synthetic grease | OT |
| 19 | Pull and remove main block (16) | |
| 20 | Remove the o-ring (18) from the main blok. Clean the surface where the o-ring (18) is attached. Lubricate and replace new o-ring (18) with synthetic grease | OT |
| 21 | Unscrew and remove the nut (21). | HW4 |
| 22 | Remove the o-rings (20) (17) from the main shaft. Clean the surface where the o-rings (20) (17) is attached. Lubricate and replace new o-rings (20) (17) with synthetic grease | OT |
| 23 | Unscrew the old plug and compensation diapghram (19) install the new one (18) | |
| 24 | Replace main block | |
| 25 | Put the main actuator (14) back into the body of the regulator. Make sure origin is under the main actuator | |
| 26 | Screw and remove the nut (25). | CW13 |



R Serie Regulator R50 Ø280 Actuator BP-MP




Before carrying out any work, it is important to ensure that the line on which the regulator is installed has been shut off upstream and downstream, and discharged.

Tighten all threaded parts with the correct torque.

Gas Pressure Regulator, R Serie

R Serie Regulator R50 Ø280 Actuator BP-MP

Reach the actuator part / change the main diaphragm




| Step | Practice | Equipment and size |
|------|---|--------------------|
| 1 | Unscrew and remove the locking protection cover (1) | CW42 |
| 2 | Turn counterclockwise and remove the adjustment screw (2) | CW24 |
| 3 | Remove the o-ring (3) from the spring cover (5). Clean the surface where the o-ring (3) is attached. Lubricate and replace new o-ring (3) with synthetic grease | OT |
| 4 | Turn counterclockwise and remove the spring cover (5) | HW80/90 |
| 5 | Remove the o-ring (6) from the spring cover (5). Clean the surface where the o-ring (6) is attached. Lubricate and replace new o-ring (6) with synthetic grease | OT |
| 6 | Remove the spring disc (4) and remove the main spring (7) | |
| 7 | Undo and remove the nut and the screw (9) | HK5 |
| 8 | Remove the main cover (8) | |
| 9 | Unscrew and remove the locking nut (10) | SW27 |
| 10 | Remove the disc of the diaphragm (11) and remove the main diaphragm (12). Clean the surface where the main diaphragm (12) is attached. | |
| 11 | Fit the new main diaphragm (12). | |
| 12 | Fit the disc of the diaphragm (11). | |
| 13 | Insert the nut (9). Tork 40Nm | SW27 |
| 14 | Fit the main cover (8). Please check; direction of the vent piece (8.1) | |
| 15 | Insert the nuts into the screws (9). Do not damage the main diaphragm (12) when installing the screws (9), check that the holes are in the center | HK5 |
| 16 | Secure the screws (9) Tork 25Nm | HK5 |
| 17 | Turn clockwise and screws the spring cover (5), check that the oring (6) is in place | HW80/90 |
| 18 | Insert the the main spring (7) and spring disc (4) | |
| 19 | Insert the o-ring (3) on the spring cover (5). | |
| 20 | Turn clockwise and screws the adjustment screw (2). | CW24 |
| 21 | Turn clockwise and locking protection cover (1) | CW42 |

Gas Pressure Regulator, R Serie
R Serie Regulator R50 Ø280 Actuator BP-MP
Reach the body part / replace the compensation membrane and the closing plug

| Step | Practice | Equipment and size |
|------|--|--------------------|
| 22 | Unscrew and remove the nut (18). | CW17 |
| 23 | Pulling up, separate the main actuator (13) from the regulator's. | |
| 24 | Disconnect the shaft (15) from the main actuator (13) by turning the block (28) counterclockwise | |
| 25 | Remove the o-ring (14) from the main actuator (13). Clean the surface where the o-ring (14) is attached. Lubricate and replace new o-ring (14) with synthetic grease | OT |
| 26 | Remove the o-ring (17) from the body (29). Clean the surface where the o-ring (17) is attached. Lubricate and replace new o-ring (17) with synthetic grease | OT |
| 27 | Detach it from the block (28) by pressing the closing plug (22) in reverse | |
| 28 | Unscrew the nut (16) to access the oring (19) | SS |
| 29 | Remove the o-ring (19). Clean the surface where the o-ring (19) is attached. Lubricate and replace new o-ring (19) with synthetic grease | OT |
| 30 | Unscrew and remove the special nut (20). Dont forget; hold the close plug (22) with hex key. Compensation diaphragm and closing plug will be separated | CW22, HK8 |
| 31 | Reassemble the new compensation diaphragm and the new closing plug with the special nut | CW22, HK8 |
| 32 | Put the closing plug (22) group back into the block (28) | |
| 33 | Turn clockwise the block (28) and screw on main actuator (13). Dont forget; check that new origin (14) main actuator is installed | |
| 34 | Insert the new o-ring (17) into its slot on the body. | |
| 35 | Mount the main actuator (13) with the block (28) on the body. | |
| 36 | Screw the nut (18). | CW17 |

R Serie Regulator R50 Ø210 Actuator AP - AAP




Before carrying out any work, it is important to ensure that the line on which the regulator is installed has been shut off upstream and downstream, and discharged.

Tighten all threaded parts with the correct torque.

Gas Pressure Regulator, R Serie

R Serie Regulator R50 Ø210 Actuator AP - AAP

Reach the actuator part / change the main diaphragm




| Step | Practice | Equipment and size |
|------|---|--------------------|
| 1 | Unscrew and remove the locking protection cover (1) | CW42 |
| 2 | Turn counterclockwise and remove the adjustment screw (2) | CW24 |
| 3 | Remove the o-ring (3) from the spring cover (5). Clean the surface where the o-ring (3) is attached. Lubricate and replace new o-ring (3) with synthetic grease | OT |
| 4 | Turn counterclockwise and remove the spring cover (5) | HW80/90 |
| 5 | Remove the o-ring (6) from the spring cover (5). Clean the surface where the o-ring (6) is attached. Lubricate and replace new o-ring (6) with synthetic grease | OT |
| 6 | Remove the spring disc (4) and remove the main spring (7) | |
| 7 | Undo and remove the nut and the screw (9) | HK5 |
| 8 | Remove the main cover (8) | |
| 9 | Unscrew and remove the locking nut (10) | SW27 |
| 10 | Remove the disc of the diaphragm (11) and remove the main diaphragm (12). Clean the surface where the main diaphragm (12) is attached. | |
| 11 | Fit the new main diaphragm (12). | |
| 12 | Fit the disc of the diaphragm (11). | |
| 13 | Insert the nut (10). Tork 40Nm | SW27 |
| 14 | Fit the main cover (8). Please check; direction of the vent piece (8.1) | |
| 15 | Insert the nuts into the screws (9). Do not damage the main diaphragm (12) when installing the screws (9), check that the holes are in the center | HK5 |
| 16 | Secure the screws (9) Tork 25Nm | HK5 |
| 17 | Turn clockwise and screws the spring cover (5), check that the oring (6) is in place | HW80/90 |
| 18 | Insert the the main spring (7) and spring disc (4) | |
| 19 | Insert the o-ring (3) on the spring cover (5). | |
| 20 | Turn clockwise and screws the adjustment screw (2). | CW24 |
| 21 | Turn clockwise and locking protection cover (1) | CW42 |

Gas Pressure Regulator, R Serie

R Serie Regulator R50 Ø210 Actuator AP - AAP

Reach the body part / replace the compensation membrane and the closing plug



| Step | Practice | Equipment and size |
|------|--|--------------------|
| 22 | Unscrew and remove the nut (18). | CW17 |
| 23 | Pulling up, separate the main actuator (13) from the regulator's. | |
| 24 | Disconnect the shaft (15) from the main actuator (13) by turning the block (28) counterclockwise | |
| 25 | Remove the o-ring (14) from the main actuator (13). Clean the surface where the o-ring (14) is attached. Lubricate and replace new o-ring (14) with synthetic grease | OT |
| 26 | Remove the o-ring (17) from the body (29). Clean the surface where the o-ring (17) is attached. Lubricate and replace new o-ring (17) with synthetic grease | OT |
| 27 | Detach it from the block (28) by pressing the closing plug (22) in reverse | |
| 28 | Unscrew the nut (16) to access the oring (19) | SS |
| 29 | Remove the o-ring (19). Clean the surface where the o-ring (19) is attached. Lubricate and replace new o-ring (19) with synthetic grease | OT |
| 30 | Unscrew and remove the special nut (20). Dont forget; hold the close plug (22) with hex key. Compensation diaphragm and closing plug will be separated | CW22, HK8 |
| 31 | Reassemble the new compensation diaphragm and the new closing plug with the special nut | CW22, HK8 |
| 32 | Put the closing plug (22) group back into the block (28) | |
| 33 | Turn clockwise the block (28) and screw on main actuator (13). Dont forget; check that new oring (14) main actuator is installed | |
| 34 | Insert the new o-ring (17) into its slot on the body. | |
| 35 | Mount the main actuator (13) with the block (28) on the body. | |
| 36 | Screw the nut (18). | CW17 |








MAINTENANCE and REPAIR


SLUM SHUT

Gas Pressure Regulator, R Serie

Equipment List for Maintenance and Repair

You must have the following hand tools for maintenance and repair. Check that the hand tools you use comply with the standards in your country.

| Equipment | DN25 – 50 BP-MP | DN25 – 50 AP-AAP | DN65 – 150 BP-MP | DN65 – 150 AP-AAP | Images |
|--------------------------|--------------------|---------------------|---------------------|----------------------|---|
| Combination Wrench | 30,10,17 | 42,10,17 | | |  |
| Hex Key Wrench T-Handle | 4 | 5 | 5,6 | 5,6 |  |
| Screwdriver Slotted | 8x150 | 8x150 | | |  |
| Hook Wrench | 58/62, 80/90 | 58/62, 80/90 | | |  |
| Circlip Pliers, External | 5-15mm | 5-15mm | 5-15mm | |  |
| Adjustable Wrench | 34 | 34 | 34 | |  |
| O-ring Tool | | | | |  |









 the unit of all dimensions is mm

Abbreviations will be used in maintenance and repair instructions


| Equipment | Abbreviations |
|------------------------------------|---------------|
| Combination Wrench | CW |
| Hex Key Wrench T-Handle | HK |
| Screwdriver Slotted | SS |
| Hook Wrench | HW |
| Double Ended Tubular Socket Wrench | SW |
| Circlip Pliers, External | CP |
| Adjustable Wrench | AW |
| O-ring Tool | OT |

Personal Protective Equipmen List

All certified technical personnel must wear personal protective equipment. You must comply with the occupational safety rules of the local authorities you are in. You should use personal protective equipment that complies with the standards of the country you are in. Personal protective equipment must meet at least the following standards

| Equipment | Standard | Images |
|--------------------------|---------------------|---|
| Industrial safety helmet | EN 397:2012+A1:2012 |  |
| Safety goggles | EN 166:2001 |  |
| Ear muffs | EN 352-1:2002 |  |
| Protective coverall | EN 14605+A1 |  |
| Visibility vest | EN 20471 : 2013 |  |
| Safety shoes | EN 20345: 2004 |  |
| Protective mask | EN149:2001 |  |
| Safety glove | EN 1082-1:1996 |  |

Slum Shut DN 1" – 2" **BP-MP** Actuator



Before carrying out any work, it is important to ensure that the line on which the regulator is installed has been shut off upstream and downstream, and discharged.

Tighten all threaded parts with the correct torque.

Slam Shut DN 1” – 2” **BP-MP** Actuator

| Step | Practice | Equipment and size |
|------|--|--------------------|
| 1 | Undo and remove the screw (13) | CW42 |
| 2 | pull off main cover (15) | CW24 |
| 3 | pull out the diaphragm group (11) | OT |
| 4 | unscrew the nut (14) | HW80/90 |
| 5 | remove the old diaphragm and replace it with a new one (11) | OT |
| 6 | replace and tighten the nut (14) | |
| 7 | replace the diaphragm assembly (11) | HK8 |
| 8 | remove the circlip (9) | |
| 11 | Lubricate and replace new felt (12) with synthetic grease | CW19 |
| 12 | Fix part (13) with the wrench and loosen part (1) and remove it | CW7 and 24 |
| 13 | replace the shutdown disk with a new one | CW32 |
| 14 | Fix part (13) with the wrench and tighten part (1) replace and fix the main cover (15) | |
| 15 | tighten the screws (13) | HK8 |

 It is recommended that slam-shut controller efficiency be checked periodically.

Cut-off Test

| Pos | Practice |
|-----|---|
| 1 | Close inlet and outlet main valves (1) (5). The controller should trigger at minimum pressure (only if so set). |
| 2 | Using a small pump or other appropriate means on the downstream vent valve (2) , raise pressure in the line to normal operating level. Relatch controller in case it has triggered following on step 1 above. |
| 3 | Simulate pressure increase until maximum triggering pressure is reached. |
| 4 | Bring the line back to full operating conditions as described in Startup procedure. |


 Reference Page 24

Controller-seal Check

| Pos | Practice |
|-----|---|
| 1 | Slowly close the main outlet valve (5) located downstream. |
| 2 | Disable the ssv unit and close the stream |
| 3 | Loosen one fitting in the line downstream of the slam-shut valve and apply soapy water in order to make sure that there are no leaks. In case of any leak being detected, proceed with the necessary maintenance of the controller. |

 Reference Page 24

Slum Shut DN 1" – 2" AP or AAP Actuator



Before carrying out any work, it is important to ensure that the line on which the regulator is installed has been shut off upstream and downstream, and discharged.

Tighten all threaded parts with the correct torque.

Slam Shut DN 1” – 2” AP or AAP Actuator

| Step | Practice | Equipment and size |
|------|---|--------------------|
| 1 | Undo and remove the screw (12) | CW42 |
| 2 | pull off main cover (15) | CW24 |
| 3 | pull out the diaphragm group (9) | OT |
| 4 | unscrew the nut (14) | HW80/90 |
| 5 | remove the old diaphragm and replace it with a new one replace (9) | OT |
| 6 | and tighten the nut (14) | |
| 7 | replace the diaphragm assembly (14) | HK8 |
| 8 | remove the circlip (11) | |
| 11 | Lubricate and replace new felt (13) with synthetic grease | CW19 |
| 12 | Fix part (3) with the wrench and loosen part (1) and remove it | CW7 and 24 |
| 13 | replace the shutdown disk (2) with a new one | CW32 |
| 14 | Fix part (3) with the wrench and tighten part (1) replace and fix the main cover (15) | |
| 15 | tighten the screws (12) | HK8 |

 It is recommended that slam-shut controller efficiency be checked periodically.

Cut-off Test

| Pos | Practice |
|-----|---|
| 1 | Close inlet and outlet main valves (1) (5). The controller should trigger at minimum pressure (only if so set). |
| 2 | Using a small pump or other appropriate means on the downstream vent valve (2) , raise pressure in the line to normal operating level. Relatch controller in case it has triggered following on step 1 above. |
| 3 | Simulate pressure increase until maximum triggering pressure is reached. |
| 4 | Bring the line back to full operating conditions as described in Startup procedure. |

 Reference Page 24

Controller-seal Check

| Pos | Practice |
|-----|---|
| 1 | Slowly close the main outlet valve (5) located downstream. |
| 2 | Disable the ssv unit and close the stream |
| 3 | Loosen one fitting in the line downstream of the slam-shut valve and apply soapy water in order to make sure that there are no leaks. In case of any leak being detected, proceed with the necessary maintenance of the controller. |

 Reference Page 24

Gas Pressure Regulator, R Serie

NOTES

For more information, contact your local sales representative or agency.



info@gastech.com.tr



www.gastech.com.tr



+90 286 501 55 11



gastech_naturalgas



www.linkedin.com/in/gastech-naturalgas-577b931a8/

GASTECH SANAYI VE TICARET ANONIM SİRKETİ
Çanakkale Organize Sanayi Bölgesi, 1. Cadde No:28 17100
Merkez-Çanakkale-TURKEY
Chamber of Commerce Çanakkale, 9492
www.gastech.com.tr info@gastech.com.tr

All rights reserved. 01/2023.

The Gastech logo is a trademark and service mark of GASTECH AS. All other marks are the property of their prospective owners. Gastech™ is a mark owned by one of the companies in the GASTECH AS. Subject to changes and errors. The information given in this document only contains general descriptions and/or performance features which may not always specifically reflect those described, or which may undergo modification in the course of further development of the products. The requested performance features are binding only when they are expressly agreed upon in the concluded contract. GASTECH AS does not assume responsibility for the selection, use or maintenance of any product. Responsibility for proper selection, use and maintenance of any product remains solely with the purchaser.